

Core Computer - 61197011

Ref.	Qty.	Part #	Description	Ref.	Qty.	Part #	Description
1	1	34039110	Fan – Chassis Cooling w/Tach	13	1	40952205	Power Supply
2	2	87842300	Nut - #6-32 Keps Hex	14	1	61196901	CBA – I/O Interface
3	15	80352304	#6-32x1/4 PPHMS	15	1	22167735	Label – Jukebox Connections
4	1	34101202	Bracket – Hard Drive Mounting	16	1	34101104	Cover – Small
5	1	40924220	Single Bd Computer Assy (B75B)	Components not shown			
6	1	22328802	Bracket – PCI Blockout	17	1	22132288	Harness Assy – Com I/O (USB)
7	1	40922699	I/O Shield (B75B)	18	1	22132270	Harness Assy – Power On/Reset
8	1	34052405	CBA – Power On/Reset	19	1	22132282	Cable – SATA Data
9	1	61197103	Housing – Core Computer	20	1	22167736	Label – NSM Music
10	1	22137302	Guide – Card				
11	1	40983503	Cover - Top	Ref	1	32218801	Hard Drive – System, NSM UK
12	1	22167705	Label – Computer Connections				

Core Computer - 61197021

Ref.	Qty.	Part #	Description	Ref.	Qty.	Part #	Description
1	1	34039110	Fan – Chassis Cooling w/Tach	13	1	40952205	Power Supply
2	2	87842300	Nut - #6-32 Keps Hex	14	1	61196901	CBA – I/O Interface
3	15	80352304	#6-32x1/4 PPHMS	15	1	22167735	Label – Jukebox Connections
4	1	34101203	Bracket – Hard Drive Mounting	16	1	34101104	Cover – Small
5	1	40924230	Single Bd Computer Assy (H310)	Components not shown			
6	1	22328802	Bracket – PCI Blockout	17	1	22132299	Harness Assy – Com I/O (USB)
7	1	40922699	I/O Shield (H310)	18	1	22145641	Harness Assy – Power On/Reset
8	1	34052405	CBA – Power On/Reset	19	1	22132282	Cable – SATA Data
9	1	61197103	Housing – Core Computer	20	1	22167736	Label – NSM Music
10	1	22137302	Guide – Card				
11	1	40983503	Cover - Top	Ref	1	32218801	Hard Drive – System, NSM UK
12	1	22167705	Label – Computer Connections				

Door Frame Assy

Ref	Qty	Part #	Description	Ref.	Qty.	Part #	Description
1	2	41024201	CBA-LED (Horiz)	10	3	28277902	#M3x10mm PPHMS
2	20	28277901	#M3x6mm PPHMS	11	4	41024202	CBA-LED (Vert)
3	20	70120511	Washer-Nylon	12	2	34115401	Bracket-Mounting LED (Vert)
4	2	34115201	Bracket-Mounting LED (Horiz)	13	1	61209801	Frame Assy-Door
5	12	28277901	#M3x6mm PPHMS	14	8.4 Ft	00710206	Gasket-Foam Tape
6	1	41023803	Diffuser	15	2	22323002	Hinge-Female
7	2	22339301	Bracket-Mounting-Diffuser	16	4	89974808	#10-32x1/2 Carriage Bolt
8	1	22339201	Bracket-Seam	17	4	87844400	#10-32 KEPS Hex MS Nut
9	1	22339101	Spacer Block-Seam				

Door Assy

Ref.	Qty.	Part #	Description	Ref.	Qty.	Part #	Description
1	1	61205005	Display Assy-18.5" HD	7,8	1	22148617	Coin Acceptor – Microcoin (UK)
2	1		Door Frame & LED Lighting	9	1	34103702	Catch-Bottom
3	1	34103701	Catch-Top	10			Currency Panel
4	2	34115002	Bracket-Mounting				
5	1	41012301	CBA-LED Controller, Lightning	Components not shown			
6	1	22346501	Plate – Hinge Lock		1	22145629	Harness Assy-LED Lights

Preamp Assy - 40991410

Ref.	Qty.	Part #	Description	Ref.	Qty.	Part #	Description
1	1	61200317	Cover – Preamplifier	7	1	61200412	Base – Preamplifier
2	1	61200707	CBA – Preamplifier	8	2	28277901	#M3x6mm PPHS
3	4	28277901	#M3x6mm PPHS	9	2	89281606	#4-24 x 3/8 PPHS (Hi-Lo)
4	1	41029701	CBA – Interface	10	1	22167736	Label – NSM Music
5	4	28277901	#M3x6mm PPHS	Components not shown			
6	2	28277908	#M3x6mm PFHS (Black)		1	34104614	Harness – Interface
					1	34104615	Harness – Interface

Amplifier Assy - 40991411

Ref.	Qty.	Part #	Description	Ref.	Qty.	Part #	Description
1	1	61200316	Cover – Amplifier	10	2	28278001	#M3 Nut
2	1	41029901	CBA – Interface	11	1	22167736	Label – NSM Music
3	4	28277904	#M3x5mm PPHS	12	1	28277901	#M3x6mm PPHS
4	1	22337204	CBA – Output Decoupling	13	2	28277908	#M3x6mm PFHS (Black)
5	2	28278001	#M3 Nut	Components not shown			
6	1	40983906	Amplifier-250 Watt w/Heat Sink		1	34104405	Harness – AC Power
7	1	61200411	Base – Amplifier		1	34104507	Harness – Audio Out
8	6	28277904	#M3x5mm PFHS		1	34113004	Cable Assy – Ribbon
9	2	28277916	#M3x12mm PFHS				

Cabinet Assy

Ref.	Qty.	Part #	Description	Ref.	Qty.	Part #	Description
1	1	40991411	Preamplifier Assy	26	1	22320601	Bracket – Reset
2	1	70091702	Solder Lug	27	1	21581802	Pushbutton Switch –ATX Reset
3	2	22323101	Cabinet Latch	28	1	70093403	Cable Clamp
4	6	25156904	Shoulder Washer	29	1	40984304	Power Distribution Assy
5	1	21256201	Tension Spring	30	4	70093402	Cable Clamp
6	1	21395811	#8-32 Nut-Elastic Stop	31	1	34103603	Baffle – Short
7	1	41030101	CBA-Interface, Microphone	32	1	34053003	Air Filter – Short
8	1 or 2	40991411	Amplifier Assy – 250 Watt	33	2	22323001	Male Hinge
9	1	61197011	Computer Assy	34	4	89974808	#10-32 x ½ Carriage Bolt
10	2	34100601	Lock Actuator	35	4	87844400	#10-32 Keps Hex Nut
11	1	34024501	Lock Bolt	36	1	41025703	Bracket – Coin Box (Right)
12	1	70163215	Cylinder Lock	Components not shown			
13	1	22321701	Left Mounting Bracket		1	61113314	Main Harness
14	2	70093402	Cable Clamp		1	21121244	Power Cord – 240V Fused
15	1	34103602	Baffle - Long		1	21121259	Power Cord – Computer Core
16	1	34053004	Air Filter – Long		1	30934235	Cable-Y Splitter, Stereo
17	1	40935205	Coin Box		1	30934236	Cable-Audio, Stereo 3.5mm
18	1	41025702	Bracket – Coin Box (Left)		1	30934231	Cable-Audio, Adaptor 36"
19	1	61199504	Cabinet		1	22346701	Filter – Audio
20	1	34118002	WIFI Assy		1	22347301	Bracket – Mounting, Audio Filter
21	1	61204001	Bracket Assy – Hanger		1	34102030	Cable-Modular (Yellow)(46.5")
22	1	22342201	Bracket – Switch Door Open		2	34102016	Cable-Modular (Green)(41")
23	1	21581802	Pushbutton Switch –Door Open		1 or 2	22132297	Cable-Ribbon (14 Conductor)
24	1	34039109	Fan with Connector		1	22212841	Cable – USB WIFI
25	1	21895503	Fan Finger Guard				

Currency Panel Assy

Ref.	Qty.	Part #	Description	Ref.	Qty.	Part #	Description
1	1	41023311	Bracket & Panel Assy	3	1	22178617	Coin Acceptor – Microcoin (UK)
2	4	70134158	#6-32x1/2 Torx Screw	4	4	87842300	#6-32 Hex Nut

Power Distribution - 40984304

Ref.	Qty.	Part #	Description	Ref.	Qty.	Part #	Description
1	1	25077506	Cover - Fuse Clip	5	1	40984404	Power Supply Cover
2	1	70072129	Fuse – 10A	6	1	22118707	Power Inlet/Switch
3	1	40994903	CBA – Power Control				
4	6	80352304	#6-32x1/4" Screw				